

Standard Phraseology for UUEL

- Подтверждаю, согласен – AFFIRM
- Не подтверждаю, отрицаю – NEGATIVE
- Указание – CLEARED, CLIMB, DESCEND, MAINTAIN, PROCEED, TURN, CONTACT
- Разрешение – APPROVED

ATC Clearance

- «Konakovo Delivery», RA(XXXXX), stand (X), information (ATIS), request ATC clearance.
 - RA(XXXXX), «Konakovo Delivery», Cleared for local VFR flight, leave control zone via (X) at (XXX) ft or below, QNH (...), SQUAWK (XXXX). For Strat-Up request contact «Konakovo Ground», 133,1.
- Readback ATC Clearance, RA04252.
 - RA(XXXXX), Readback is correct.

Start-Up request

- «Konakovo Ground», RA(XXXXX), stand (X), information (ATIS), request Start-Up.
 - RA(XXXXX), «Konakovo Ground», Start-Up approved.
- Start-Up approved, RA(XXXXX).

Taxi request

- Ready for air taxi, RA(XXXXX).
 - RA(XXXXX), air taxi to holding point RWY (X) via TWY (X).
- Air taxiing to RWY (X) via TWY (X), contact «Konakovo Tower», 133,1, RA(XXXXX).
- Approaching holding point RWY (X), RA(XXXXX).
 - RA(XXXXX), Contact «Konakovo Tower», 133,1.
- «Konakovo Tower», 133,1, RA(XXXXX).

Take-Off request

- «Konakovo Tower», RA(XXXXX), holding short RWY (X), ready for departure.
 - RA(XXXXX), «Konakovo Tower», wind XXX degrees X m/s, cleared for take-off, RWY (X).
- Cleared for Take-Off, RA(XXXXX).

Local VFR

- **EXERCISE 1: LEAVING CONTROL ZONE AFTER DEPARTURE**
 - Approaching (XXXXX), maintaining (XXX) ft, RA(XXXXX).
 - *RA(XXXXX), frequency change approved.*
 - Roger, RA(XXXXX).

- **EXERCISE 2: TRANSITION TROUGH CONTROL ZONE**
 - «Konakovo Tower», RA(XXXXX), approaching (XXXXX), maintaining (XXX) ft, QNH (XXXX), request transition from (XX) to (XX).
 - *RA(XXXXX), «Konakovo Tower», QNH (XXXX), transition approved. Report (XXXXX).*
 - QNH (XXXX), Transition approved, Report (XXXXX), RA(XXXXX).
 - Approaching (XXXXX), RA(XXXXX).
 - *RA(XXXXX), FRQ change approved.*
 - FRQ change approved, RA(XXXXX).

- **EXERCISE 3: ENTERING CONTROL ZONE, HOLDING, GO AROUND, LANDING, TAXIING**
 - «Konakovo Tower», RA(XXXXX), Information (ATIS), request entering to control zone via (XXXXX), at (XXX) ft, QNH (XXXX), for landing at UUEL.
 - *RA(XXXXX), «Konakovo Tower», Cleared to enter Control zone via (XXXXX) at (XXX) ft, QNH (XXXX). Hold over (X) due traffic.*
 - QNH (XXXX), maintaining (XXX) ft, cleared to enter CTR via (XXXXX), holding over (X), RA(XXXXX).
 - *RA(XXXXX), cleared for visual APP for RWY (X), join base, report ready to land.*
 - Cleared for visual APP for RWY (X), join base, report ready to land, RA(XXXXX).
 - On final, RWY inside, ready to land, RA(XXXXX).
 - *RA(XXXXX), wind (XXX) degrees, (XX) m/s, cleared to land, RWY (X).*
 - Cleared to land, RWY (X), RA(XXXXX).
 - *RA(XXXXX), GO AROUND, I SAY AGAIN, GO AROUND, RWY is blocked. Climb (XXX) ft on RWY heading, then join left downwind.*
 - Going around, climbing (XXX) ft RWY heading, joining downwind, RA(XXXXX).
 - Approaching base, RA(XXXXX).
 - *RA(XXXXX), cleared for visual APP for RWY (X), report ready to land.*
 - Cleared for visual APP for RWY (X), report ready to land, RA(XXXXX).
 - On final, RWY inside, ready to land, RA(XXXXX).
 - *RA(XXXXX), wind (XXX) degrees, (XX) m/s, cleared to land, RWY (X).*
 - Cleared to land, RWY (X), RA(XXXXX).
 - *RA(XXXXX), on the ground at (XX), vacate via (X), stand (X).*
 - Vacating via (X), stand (X), RA(XXXXX).
 - RA(XXXXX), stand (X), leaving your FRQ.

Emergency and abnormal situation

Fuel emergency

- **MAYDAY, MAYDAY, MAYDAY!** RA(XXXXX), Fuel emergency. Request priority landing.
 - *RA(XXXXX), Roger MAYDAY, cleared to land, RWY (X), QNH (XXXX).*

Precautionary landing

- «Konakovo Tower», RA(XXXXX), we have warning indication, request precautionary landing.
 - *RA(XXXXX), roger. Precautionary landing approved. Please contact the Tower using mobile phone after landing or report your intentions when ground-check is completed.*
- Landing approved, call you back after landing, RA(XXXXX).
- «Konakovo Tower», RA(XXXXX), airborne, normal flight, continue to my destination.
 - *RA(XXXXX), Roger.*

Inadvertent IMC

- «Konakovo Tower», RA(XXXXX), **PAN, PAN, PAN!** Inadvertent IMC. Request 1-80 turn to avoid weather.
 - *RA(XXXXX), roger PAN. Cleared 1-80 turn, report completed.*
- Will report VMC, RA(XXXXX).
- Out of weather, VMC, RA(XXXXX).
 - *RA(XXXXX), roger.*