MOSCOW, RUSSIA

SHEREMETYEVO

AREA CHART - ICAO

DEPARTURE ROUTES



RTE IDENT	ROUTING
BELAG 1E	From Buzharovo NDB proceed to CRP BELAG.
BG 1E	From Buzharovo NDB proceed to CRP MAKSI, then to Karmanovo NDB.
FV 1E	From Ivanovskoye NDB (FL130 or above) proceed to CRP ARSEP, then to CRP GOTMA, Klimovsk NDB, Glotayevo NDB, Venev NDB.
FV 2E	From CRP DEDUM proceed to CRP ARSEP, then to CRP GOTMA, Klimovsk NDB, Glotayevo NDB, Venev NDB.
FV 3E by ATC	From CRP BESTA proceed to NCRP RUGEL, then to NCRP GEKLA, Kartino NDB, Glotayevo NDB, Venev NDB.
OBELU 1E	From Buzharovo NDB proceed to CRP OBELU.
SUGIR 1E	From Ivanovskoye NDB (FL130 or above) proceed to CRP UMBEG, then to Kamenka NDB, CRP SUGIR.
SUGIR 2E	From CRP DEDUM proceed to CRP ARSEP, then to CRP GOTMA, Kamenka NDB, CRP SUGIR.
NE 1E	From Kostino NDB proceed to Nerl NDB.
NOGTI 1E by ATC	From CRP BESTA proceed to NCRP RUGEL, then to Maryino NDB, CRP DAKLO, CRP NOGTI.
TIMIG 1E by ATC	From Kostino NDB proceed to CRP TIMIG.
SF 1E	From CRP BESTA proceed to NCRP RUGEL, then to Maryino NDB, CRP DAKLO, Cherusti NDB.

CHANGE: ATC route